



ATTENTION CONSTRUCTION:
 CABLE SHOULD BE PLACED FROM THE FIELD BACK TO THE PFP.

AT ALL BORE LOCATIONS THAT REQUIRE TETHERS
 BE PULLED THROUGH A BORE FOR PLACEMENT,
 PLACE INNERDUCT TO FACILITATE PULLING.

FOR ALL 845C INNERDUCT PLACEMENTS:
 USE 1.6" I.D. INNERDUCT

3 DAY PLAN

DAY 1

DAY 2

DAY 3

1	2	3	4	5	6	7	8	9	10
159	79	17	20	20	21	48	25	87	37
0	0	0	0	0	0	0	0	0	0
159	79	17	20	20	22	48	25	87	37
17	8	2	2	2	2	6	3	10	4

11	12	13	14	15	16	17	18	19	10
9	16	92	34	19	15	24	48	11	
0	0	1	0	1	0	0	0	0	0
9	16	88	34	20	15	24	48	11	
1	2	11	3	3	2	1	6	3	

DESIGNED BY PIVOTAL
 ENGINEERING CONTACT:
 DAVID SAKAMOTO
 (360) 882-4268

PROJECT # A02CYB6		DATE SVC REQ'D 12/31/2023
NPANNX 713462	GEO LOC WL4462	CLI HSTNTXFA
PRIMARY ENGR.: PACE, JEFF A		
ENGR. ID: JP9438	PERMIT REQ'D: N	
PHONE #: 2817854953	PRINT 2 OF 40	